



DL-3RB / DL-5RB 他社三脚適合表

	型番	三脚型番	脚バンド設定位置
Sachtler 75mm ϕ	Ace M GS	Ace 75/2 D	
	Ace L GS CF	Ace 75/2 CF	
	Ace L MS CF	Ace 75/2 CF	
	FSB 4/6/8	ENG75/2D, ENG75/2DHD, DA75L, SpeedLock75 CF	
	FSB 6T/8T	ENG75/2D, ENG75/2DHD, DA75L, SpeedLock75 CF	
Sachtler 100mm ϕ	VIDEO 18S1/20S1	SpeedLock CF, CF100L, ENG2D, ENG2CF, DA100L	
	DV 10SB/12SB /15SB	SpeedLock CF, CF100L, ENG2D, ENG2CF, DA100L	
	CINE 7+7HD	SpeedLock CF, CF100L, ENG2D, ENG2CF, DA100L	

DL-3RB / DL-5RB 他社三脚適合表

	型番	三脚型番	脚バンド設定位置
Vinten	Vision blue Vision blue3 Vision blue5	3819-3 V3822-0001 3766-3	
	Vision 8AS Vision 10AS Vision 100	3821-3 3772-3 3773-3 3884-3	
Manfrotto	501HDV	546B, 546GB	
	504HD	545B, 545GB 546B, 546GB	
	509HD	545B, 545GB	